




QUICK START GUIDE




YOUR REMOTE

- ① Power On/Off
- ② **TiVo button:** Takes you to the Home Screen
- ③ **"i" button:** Program information
- ④ **Navigation Ring:** UP, DOWN, LEFT (rewind), RIGHT (fast-forward)
 - a. While watching video, press LEFT to rewind and RIGHT to fast-forward up to three times for increasing speeds
 - While fast-forwarding or rewinding, press and hold RIGHT/LEFT again to skip ahead/go back 15 minutes.
 - b. When watching tv, press UP and hold RIGHT to skip ahead 30 seconds
- ⑤ **OK button:** Use to choose menu items, pause/play TV
- ⑥ **Back button:** Start full-screen video on The Home Screen, and goes back to the previous screen on other menu screens
- ⑦ **Exit button:** Return to the previous channel
- ⑧ **Google Assistant button:** For the best experience using the Voice Command functionality, sign in to your Google account or sign up if you don't already have one. Please refer to accounts.google.com/signup for more information on creating an account
- ⑨ **GRID button:** Take you to the Apps & Games screen

For remote pairing instructions to your TV or other device, please visit HelloTDS.com/support

NAVIGATING TDS TV+



Settings Menu Navigation Bar SmartBar

Your TDS TV+ experience begins with the Home Screen. This screen includes live video playing in the background, the middle Navigation Bar, and lower SmartBar (program recommendations).

NAVIGATION BAR

The Navigation Bar provides multiple options and is the central hub of your TDS TV+ experience. Scroll left or right and press the OK button to select an option.

WATCH TV: To watch live TV shows, go directly into the live TV channel playing in the background

MY SHOWS: Access a complete list of your TV recordings, On Demand shows you've saved, or saved shows from streaming apps like Netflix

WHAT TO WATCH: Suggests various, popular categories of programs to watch

GUIDE: Displays the channels included in your lineup

APPS & GAMES: Find and download your favorite apps

ON DEMAND: Explore our library of favorites, classics, new releases, and more


SEARCH: Look for content included in your lineup, On Demand, and streaming apps

MENU: Press LEFT past Watch TV to access. Here you can customize settings such as Parental Controls, Favorite Channels, and other User Preferences.

SMARTBAR


The SmartBar learns and recommends shows for you based what you usually watch at a particular time and/or day.

TIP:  The green "Start Over" icon appears next to certain shows listed in your guide. It means you can start the program over from the beginning. Press and hold the OK button to enable Start Over.




RECORDING SHOWS & MOVIES

- When watching TV or searching for upcoming airings in the Guide, press the "i" info button for the fastest way to record just this episode or movie or set up a OnePass for series recordings.
- Set up a series to record in OnePass with a variety of options to fit your recording preferences. See your User Guide for more information about recordings and OnePass.



DVR STORAGE

- OnePass™ helps you manage your recordings so you never miss an episode or overtime of the game.
- To access recordings, select My Shows from the Navigation Bar.
- Record up to 10 shows simultaneously.
- Total DVR storage space used is indicated by a percentage displayed at the top bar of My Shows.



TDS TV+ ON YOUR DEVICES

- TDS TV+ is available in the Apple and Google app stores. The app can also be downloaded on to AppleTV, Amazon Fire (TV and Cube) and Android TV.
- For TV away from home, go to content provider websites or apps and log in using your TDS account.

TROUBLESHOOTING

- For the best connection, use an ethernet cord to connect your TDS TV+ equipment to a modem.
- Location of your Wi-Fi router and Wi-Fi signal strength may impact video quality.
- To reboot the TDS TV+ receiver, hold down its power button for 6-10 seconds or unplug the receiver and plug back in.

ADDITIONAL RESOURCES

TDS TV+ User Guide:

Located in the Welcome Kit you were provided with during install. It includes detailed and expanded explanations of TDS TV+ features and functionality.

Online Customer Support:

HelloTDS.com/support

Customer Care:

1-844-848-9087, available 24/7.

Delinquent accounts may lose service. Certain services not available in all areas. Price may vary by serving area and is subject to change without notice. Services subject to TDS Terms of Service at hellotds.com/tos, TDS Privacy Policy at hellotds.com/privacy, and TDS Acceptable Use Policy at hellotds.com/use. TDS® is a registered trademark of Telephone and Data Systems, Inc. Copyright © 2020, TDS Telecommunications LLC, All Rights Reserved. 202633/5-20/12313